Contents

About This Manual vii
Customer Support ix

Chapter 1 Introduction 1

1.1 Parallel Programming on the CM-5 1

1.2 The SPMD Programming Model 2
1.2.1 Data Parallel Programming 2
1.2.2 Message-Passing Programming 3

1.3 Scalable Computing 4

1.4 CM-5 Hardware 4
1.4.1 Processors 4
1.4.2 Vector Units 5
1.4.3 Networks 6

1.5 CM-5 Software 6
1.5.1 Data Parallel Software 7
1.5.2 Message-Passing Software 7
1.5.3 Assemblers 7
1.5.4 CMAX 8
1.5.5 The CMOST Timeshared Operating System 8
1.5.6 Prism Programming Environment 9

1.6 I/O on the CM-5 9
1.6.1 Hardware 9
1.6.2 Software 10

1.7 CM-5 On-Line Documentation 11

Chapter 2 The Basics 13

2.1 The User's View of the CM-5 14

2.2 Gaining Access 15
2.2.1 The `rlogin` Command 15
2.2.2 The `rsh` Command 16

2.3 Writing and Compiling Your Program 16
2.3.1 Linking 17

Copyright © 1993–1994 Thinking Machines Corporation

2.4 Executing Your Program 17
2.4.1 Providing Accounting Information 17
2.4.2 Executing in Batch Mode 18
UNIX Batch Commands 18
DJM (Distributed Job Manager) 18
The NQS Batch System 19
2.5 Debugging Your Program 20
2.5.1 The Errors File and Core Files 20
2.5.2 Fortran Tracebacks 22
2.6 Timing a Program 22
2.7 Getting Information 23
2.7.1 Finding Out about the CM-5's Configuration 24
2.7.2 Finding Out about the Status of the System 25
2.7.3 Finding Out about the Status of DJM 27
2.7.4 Finding Out about the Status of NQS 28
2.8 Obtaining On-Line Documentation 29
2.8.1 CMview 29
2.8.2 Man Pages 31
2.8.3 PostScript Files 32

Chapter 3 Using Prism 33

3.1 Starting Prism 34
3.2 A Tour of Prism 34
3.3 Executing a Program 36
3.3.1 Interrupting, Continuing, and Single-Stepping 37
3.4 Debugging a Program 38
3.4.1 Setting a Simple Breakpoint 38
3.4.2 Using Commands 39
3.4.3 Using the Event Table 39
3.4.4 Displaying and Moving through the Call Stack 40
3.5 Visualizing Data 41
3.5.1 Other Representations 43
3.5.2 Other Methods of Choosing the Data to Visualize 44
3.6 Obtaining Performance Data 45
3.6.1 Collecting Performance Data 46
3.6.2 Displaying Performance Data 46
3.6.3 Other Performance Analysis Features 48
3.7 Getting Help 49

Copyright © 1993–1994 Thinking Machines Corporation

3.8 Customizing Prism 50
3.9 Leaving Prism 50
3.10 Commands-Only Prism 50
3.11 Using Prism with CMAX 51
3.12 Node Prism 51
3.12.1 Using PN Sets 52
The PN Sets Window 52
Using PN Sets in Commands 53
3.12.2 Displaying Data, the Call Stack, and Performance Information 54

Chapter 4 CM-5 Languages and Libraries 57

4.1 CM Fortran 57
4.1.1 Programming Models 58
4.1.2 Intrinsic Functions 59
4.1.3 Utility Library 59
4.1.4 Development and Monitoring Facilities 59
4.1.5 Documentation Provided 59
4.2 C* 60
4.2.1 Programming Models 61
4.2.2 Documentation Provided 61
4.3 CM Scientific Software Library 61
4.3.1 Linear Algebra 62
4.3.2 FFTs 63
4.3.3 Ordinary Differential Equations 63
4.3.4 Linear Programming 63
4.3.5 Random Number Generation 64
4.3.6 Statistical Analysis 64
4.3.7 Communication Functions 64
4.4 Visualization Programming 65
4.4.1 A Distributed Graphics Strategy 65
4.4.2 An Integrated Environment 65
4.4.3 The CM/AVS Visualization Environment 65
Documentation Provided 66
4.4.4 Visualization Programming with CMX11 66
Creating and Controlling a Display 67
Rendering Your Data 67
Graphics Programming 67
Documentation Provided 68

Copyright © 1993–1994 Thinking Machines Corporation

4.5 Message Passing with CMMD 68
4.5.1 Programming Models 69
4.5.2 Cooperative Processing and Asynchronous Processing 69
4.5.3 Active Messages and Block Transfers 70
4.5.4 CMMD I/O 71
4.5.5 Supporting Utilities 71
4.5.6 Documentation Provided 71
4.6 The CMAX Converter 72
4.6.1 Documentation Provided 74
4.7 Assembly Language 74
4.7.1 Documentation Provided 75

Appendix A Moving from the CM-2 to the CM-5 77

A.1 Updating the Program 77
A.1.1 CM Fortran 77
A.1.2 C* 78
A.2 Compiling and Linking 79
A.2.1 CM Fortran 79
A.2.2 C* 79
A.3 Executing 79
A.4 *Lisp 80

Appendix B A Sample CM Fortran Program 81

Appendix C Glossary 83

Index 89

CMOST Version 7.3, April 1994
Copyright © 1993–1994 Thinking Machines Corporation