

113A Data Set Modification Kit For Automatic Disconnect

INSTALLATION INSTRUCTIONS

1. Remove rear cover of Dataset
2. Remove Red line cord lead from screw terminal. Remove green lead from same terminal.
3. Install diode with ~~anode~~^{cathode} end to screw terminal.
4. Install red line cord lead and green lead removed from terminal to ~~cathode~~^{anode} end of diode.
5. Replace cover.