PLEASE RETURN 'TO

SYSTEMS FILE

PROJECT FILE
Data Systems Division

	U I				
Cate	gorv	\mathcal{I}	. A	.7	
Date					

Area/Location_	Systems Development/Pough	kecosie	Date <u>March 31, 1964</u>
Project	7289 Drum Channel		Project No.
File Section	Functional Specifications /		Section No.
Systems Plannin	~ ^ ^ ·	Planning Rep. or Project Manager	H.J. Kozuch

1 DESCRIPTION

The 7289 Drum Channel permits the attachment of the 7320A Drum Storage Unit to the 7090/94/94-II Systems. The 7289 Drum Channel provides for connecting four 7320A Drum Storage Units and attaches to the 7090/94/94-II Systems in the same manner as a 7909 or 7607 Data Channel. The data characteristics are listed in Table 1.

2 GENERAL CHARACTERISTICS

Data is stored on the drum in groups of 1024 words, 4 bits in parallel. Two of these groups are contained around the drum in each sector; 16 sectors constitute a logical drum and there are 6 logical drums per physical drum (Figure 1). A logical drum provides for storage of 32,768 words (36 bits/word).

Each word within a logical drum is individually addressable with an address from 00000 to 777778. The 6 logical drums of a physical drum are addressable from 1 to 68. The four physical drums are addressable from 0 to 38. These three address fields are specified by the command referred to by a RCH instruction.

Reading or writing may start anywhere with any number of words.* However, reading or writing may not proceed from one logical drum to another without a new RDS or WRS. If the word count is not zero when address 77777 on any logical drum is reached, the end of file indicator is turned on and the drum is logically disconnected. When writing, if the starting address specified by the RCH is not the address of the beginning of a 1024 word block (00000, 02000, 04000, etc.), the portion of the group preceding the starting address will be erased. Also, if word count does not go to zero coincident with the end of a group, the remainder of the group will be erased. However, while reading, a single word* or any number of words may be transmitted.

At the end of each 1024 word group, a 4 bit LRCR character is written. If, while reading, this character does not compare with the character generated from the data, the redundancy (LRCR) check indicator is turned on and the drum is logically disconnected.

^{*} Except for restrictions described in IOCP and IOCT commands (Sections 3.2.2 and 3.2.3).

Area/Location	System Develor	oment/Pougl	nkeepsie	Date	March 31, 1964
Project	7289 Drum Cha	nnel		Proje	ct No.
File Section	Functional Spec			Section	on No.
Systems Planning or Area Manager	J. A. G	iroux	Planning Rap. of Project Manage	r И.С.	Kozuch Kozuch
				. •	
3 OPERATING	G CHARACTER	ISTICS	.		
3.1 Instru	ctions				
3.1.1	RDDB - Read	Select Drur	n Channel D		
	+ 0762		T.		02330
	S, 1	11 1.2	17 18-20	21	35
	Description:		uction causes the mation from any ge.		
	Execution:	and Load (but the dru A RDS giv	Channel may be	given at any ad until the nnel is busy	RCH is executed will halt
		Addresses	for other chan	nels are:*	
			Channel C Channel E Channel F Channel G Channel H	3330 4330 5330 6330 7330	
3.1.2	WRDB - Wr	rite Select D	rum Channel B		
**************************************	+ 0766		17777 T		02330

Description: This instruction causes the computer to prepare to write information on any drum on Channel B from core storage.

rea/Location_	Systems Development/Poug	hkeepsie	Dote January 30, 1964	
roject	7289 Drum Channel		Project No.	
ile Section	Functional Specifications		Section No.	
ystems Plannin or Area Manag		Planning Rep. or Project Manager	I J. Kozich	.*

3.1.2 WRDB - Write Select Drum Channel B - (Continued)

Execution:

The designated channel is prepared to write. A Reset and Load Channel may be given at any time later, but the drum is not selected until the RCH is executed.

A WRS given while the channel is busy will haltprocessing until the channel is available.

Addresses for other channels are listed under RDDB.

3.1.3 RCHB - Reset and Load Channel B

	- 0540		F	1111	M	Т		Y	·
 S, 1		11	12-13	14	17	18-20	21		35

Description:

If Channel B has been selected by either a RDS or WRS, the $C(Y)_{4.5}$ replace the contents of the physical drum select register, $C(Y)_{15-17}$ replace the contents of the logical drum select register, $C(Y)_{2\cdot 1-35}$ replace the contents of the drum address register and $C(Y)_2$ replace the contents of the chain mode control indicator. In addition, the number Y plus one replaces the C (location counter).

If the operation is a read and the chain mode bit is absent or if the operation is a write, the channel selects the proper drum and starting address and executes the command at Y + 1 to begin data transmission. If the operation is a read and the chain mode bit is present, the proper drum and starting address is selected and the first word read from the drum becomes the first control word used.

Execution:

If Channel B is not selected when the RCHB is given, the I/O check indicator is turned on. For each RDS or WRS, the corresponding RCHB must be given if any transmission between storage and the selected drum is to take place. For each RDS or WRS, only one RCHB may be given. A RCHB given while the

Area/Location	Systems Development/Pour	ghleepsie	_Date _	March 31, 1764	_
roject	7289 Drum Channel		Pro	ject No.	-
ile Section	Functional Specifications		Sec	tion No.	~
Systems Planning or Area Manager	J. A. Throux	Planning Rep. or Project Manager	4 11.	J. Kozueli .	-
	•				

3.1.3 RCHB - Reset and Load Channel B-

(Continued)

channel is busy will wait for the channel to cease operation and will then I/O check.

Instruction codes for other channels are as specified in the 7094 Reference Manual A22-6703.

3.1.4 Store Channel B Diagnostic (SCDB)

	- 0644	-	. F		T		Y	
S, 1	•	11	12-13	14	17 18-20	21	. 3	5

Description:

Execution of this instruction causes the specified channel to be selected and the specified channel's diagnostic indication to be stored in location Y.

Channel Indicator	Y-Position
I/O Check	5
B cycle late	1 CDR 10 TER)
Invalid Command	2
Physical Drum Select 4, 5	3, 4
Logical Drum Select 15-17	5-7 SECTOR
Drum address register 1 - 4	8 - 11 (Most significant bits)
Group	12
LRCR register 1 - 4	14-17
File protect on	13
Reserved	18-35

Codes for other channels are as specified in the 7094 Reference Manual, A22-6703. Store Channel or Store Channel Diagnostic Instructions must be given only when the channel is not in use.

•			
Area/Location	Systems Development/Por	ighkoepsie	Date <u>January 30, 1964</u>
roject	7289 Drum Channel		Project No.
ile Section	Functional Specifications		Section No.
Systems Planning or Area Manager	J. a. Mount	Planning Rep. or Project Manager	H. J. Kozuch
•		e en	
3.1.5	Other	• •	
	The following instruction (RDC), TRC, TEF, IOT, (is are compatible w	rith (7607) operations:
	The following instruction cause a halt in processin SDN. The following instruction but will not cause a halt	ng: LCH, BSR, B	SF, WEF, REW, RUN, 289 have no function,
3.2 <u>Gomn</u> 3.2.1		or present to be tes	sted: BTT, ETT.
	0 C	0	Y
	S-2 3	17 18 19 20	35
	core stor	re transmitted bety age beginning with l smission is under c	location Y. The
	reduced to has been drum unti transmit reached,	reached, the channed the EOO is reached this data to CPU. If the URCE characte	nd of a group (EOG) cl continues to read cd, but does not
	drum is o	isconnected.	•

If an EOG is reached before word count has gone to zero, the LRCR character is checked and reading continues from the next group.

Area/Location	Systems Development/Po 7289 Drum Channel		Project No.
Project	Functional Sperifications		Section No.
File Section	A.a Anon	Planning Rep. or	H. J. Kozuch
Systems Planning or Area Manager_	J. A. Giroux	Project Manager	H. J. Kozuch

Write Operation: When C words have been written on the drum, the rest of the group is filled with zeros and a LRCF character is written. The channel is then disconnected.

3.2.2 IOCP - Input/Output under Count Control and Proceed

	Y	١
4	•	
S-2 3 17 18 19 20	35	ı

Description:

C words are transmitted between the drum and core storage beginning with location Y. When C is returned to zero, the next sequential command is taken from one of two places:

- a. If reading, and not in chain mode, or writing, the next command is found in the location following the IOCP in core storage.
- b. If reading, and in chain mode, the next sequential command is found on the drum at the address following the last word transmitted to core.

Execution:

Read Operation: C words are read from drum and stored in consecutive storage locations beginning with location Y. When the word count has been reduced to zero, the channel executes the next command.

Write Operation: C words from storage beginning with location Y are written on drum. When the specified words have been written, the channel proceeds to the next sequential command.

General: When either reading or writing and executing IOCP command from core storage, the word count may not be less than three.

10 6 (20)

•					•		2 3 2 2		
rea/Location_	System D	evelopmer	nt/Poughkee	psie ·		Date1	March 31,	1964	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
roject	7289 Dru	m Channel	1			Proje	ct No		
ile Section_	Functiona	al Specific	ations		~ 		on No.		
ystems Planning or Area Manag		. Giroux		anning froject A	Rep. or Manager		Kozuch		
3.2.3	IOCT	- Input/O	Output Under	Count	Contro	l and Trar	ısfer		
	5		С	0		Y			
	S-2	3	. 17	18	19	20		35	
	Descri	ption:	the IC b. If the is traits fou	ge begined to a one of channe and is CT in channe ansferred on t	inning vizero, to fix two plus lis write found in core state to the drunk he drunk.	with locati he next co	on Y. Whenmand is rum, the retion follower, on drum, could the next ddress followers.	next ving ontrol t com	nand
	Execu	tion:	Same as I		a (Leiis		-		
3.2.4	Comm	and Chain	ning	•	•				* *
	the ch The cl preser The cl	annel need hain mode nce of a bi hannel wil	rom the drum d not refer to may be ente it in position I proceed in ther an IOCT	o core ered by 2 of the sequen	storag an IOC ne word nce thr	e for its n CT.comma d referenc ough mem	ext comm .nd or by t ed by a R ory execu	and. the CH.	
	Once (cause	chain mod ed by IOCI	le is entered D or EOF) odrum are ex	, it ma	y not l	oe left unti	l a discon	nect	
3.3	Load	Drum But	ton	. •	• • •				
	A loa	d drum bu	tton is provi	ded on	the 71	51 console	to allow	loadin	g

of systems from the drum.

		_	. A Doughtroongie	Date March 31, 1964
rea/Location			relopment/Poughkeepsie .	Project No.
roject	7289 D	rum (Channel	Section No.
ile Section_		mal S	Specifications Planning Rep. or	H. J. Kozich
ystems Planr or Area Mar	ning nager <u>J</u>	. A.		H. 9. Kozuch
3.3			ton (Continued)	0 1 and
	2 of logica stored in	al dru corre	drum button is pressed, the words am 1 of physical drum 1 on a partice sponding locations in memory. The location 0 and the CPU executes are command at location 0 may be a	The channel then executes the instruction at
3.4	Timing C	onsid	eration	
	Because of indirect a	of the	e high speed of the 7320A drum (8. ssing and TCH commands are not ds that are executed from storage	4 us per word average), allowed. All IOCP and must have a word count
	of three	or gr	eater.	
	are oper	ating	tion of the 7289 cannot be guarante simultaneously.	
	Imprope	r ope	ration, due to short word counts i multaneous channel operation, wil el will disconnect.	n IOCP's, IOCT's or l result in an I/O check
3.5	Check C	ondit	ions	
	There a	re tw	o check indicators in the 7289 cha	nnel.
	3.5.1	1/0	Check Give	euted and the channel is
		1,	A Reset and Load Channel is exer not selected.	
\mathcal{B}	Time late	2.	If, when writing, the channel dat loaded with a word from storage are to be sent to the drum regist	er.
	<i>u</i>	3.	If, when reading, the channel da its contents by the time new data drum register.	ta register has not stored are to be sent from the

The particular channel is designated at time of channel installation.

weld com.

A command other than IOCP, IOCT, or IOCD is decoded.

rea/Location	System	is Development/Poi	ughkeepsie	Date March 31, 1964
roject		rum Channel		Project No.
ile Section		onal Specifications		Section No.
ystems Planni or Area Mana	ing	J. A. Giroux	Planning Rep. or Project Manager	H. D. Kozuch
	3.5.2	Redundancy Check		
		While reading, the read does not comp	check character generate with the character	ated from the data written on the drum.
-	File Prot			
•	toggle sw	ritches on the opera	ndividually file protected tor's panel on the 7289 during a write operation, but the 7289 will hang	on, the main frame will
3.7	Additiona	al Core Storage		
	11 451	to the operation in Features Bulletin L	core storage in the 728 the 7909 Data Channel 22-6636-1, IBM 7090 a	as described in
3.8	Operator	's Panel		
	The follo	owing switches and	indicators are availabl	e to the operator:
	3.8.1	Switches		
		Power On/Off	Applies primary power and drum.	r to the channel
		DC On/Off	Applies DC power to t drum if Power On-Off	the channel and f switch is on.
		File Protect	24 switches for file p logical drum of the fo physical drums.	rotecting each our possible
		File Protect Rese	protect trigger and File protect switch	for resetting file d file protect indicator. h of the selected drum to permit resetting.

Apostion S	ystem Development/Poug	hkaapsi: Date January 30, 1964
	Drum Channel	Project No.
		Section No.
ems Planning	J. A. Caroux	Planning Rep. or # 1 Kozuch Project Manager II. J. Kozuch
-		
3.8.2	Indicators	
	Power On	Indicates that primary power is on.
	DC On	Indicates that DC power is on.
	Power Check	Indicates a power failure in channel
	Ready	Indicates that channel is in ready status.
	File Protect	Indicates an attempt to write a file protected logical drum
	Drum Register	Displays the contents of the 36 position drum register.
	Location Counter	Displays the contents of the 15 position location counter.
	Address Counter	Displays the contents of the 15 position address counter.
	Word Counter	Displays the contents of the 15 position word counter.
	Drum Address Counter	Displays the contents of the 15 position drum address counter
	Drum Select	Displays the contents of the 2 position physical drum select register and the
		3 position logical drum select register.
	Drum Counter	Displays the contents of the 10 position drum counter which counts the word in
		a sector.
	Operation Register	Displays the contents of the 3 position operation register.

area/Location System Development/Po	
roject 7289 Drum Channel	Project No.
ile Section Functional Specifications	Section No.
or Area Manager J. A. Ciroux	Planning Rep. or & J. Kozuch Project Manager II. J. Kozuch
3.8.2 Indicators (Continued	d)
Control Ring	Displays the contents of the 6 position control ring which generates control signals for the channel and drums.
Character Counter	Displays the contents of the 4 position character counter. All indicators off represents a count of one.
Character Register	Displays the contents of the 4 position character register.
Read	Indicates that channel is in read status.
Write	Indicates that channel is in write status.
Gap Search	Indicates successful completion of RDS or WRS and RCH prior to sensing
	index gap.
Group	Indicates which of the two 1024 word groups in a sector is positioned under the heads. Off for first or low order address
	group, on for second or high order address group.
Address Compare	Indicates a compare or match condition of the Drum Address Register and Drum Counter.
Head Select	Indicates control signal sent to drum to activate selected heads.
Write Gate	Indicates control signal sent to drum to condition drum for writing.
LRCR	Displays the contents of the 4 position Longitudinal Redundancy Check Register.
LRCR Check	Indicates the Longitudinal Redundancy Checcondition described in Section 3.5.2.

Area/Location System Development/Pou	ghkeepsie Date January 30, 1964
Project 7289 Drum Channel	Project No.
ile Section Functional Specifications	Section No.
or Area Manager J. A. Giroux	Planning Rep. or H. J. Kozuch Project Manager H. J. Kozuch
3.8.2 <u>Indicators</u> (Conti	nued)
No Drum	Indicates an attempt to address a non-existent physical drum or a drum with power off.
I/O Check	Indicates the I/O check conditions described in Section 3.5.1.
B Late	Indicates an overrun condition wherein the channel does not receive a storage reference (B) cycle in time.
End of File	Indicates an attempt to read or write past the boundaries of a logical drum.
Command Word Control	For use with additional core storage. See Section 3.7.
Data Word Control	For use with additional core storage. See Section 3.7.
3 0 C F Panai	

The following switches and indicators are for maintenance:

3.9.1 Switches

CPU/Test

When this switch is in the CPU position, the channel may be operated from the system. This switch must be in test for all other switches to function, except stop on error.

Area/Location <u>S</u>	System Development/Poug	hkeepsie Date January 30, 1964
Project 7289	Drum Channel	Project No.
ile Section	Functional Specifications	Section No.
systems Planning or Area Manager	J. A. Chroux	Planning Rep. or & J. Kozuch Project Manager H. J. Kozuch
3.9.1	Switches (Continue	ed)
	On-Line/Off-Line	When this switch is in the off-line position, the drum may be operated without disturbing the CPU. Data and commands are taken from the CE Panel. When this switch is in the on-line position, data and commands are taken from core storage.
	Stop on Check On/Off	When this switch is on, all counters stop when check condition (I/O Check, LRCR, or data compare) occurs. This allows examination of the conditions which caused the check. This switch is functional at all times.
	Data Compare On/Off	When this switch is on, read data is compared with the contents of the drum register. This functions only in off-line mode.
		When this switch is on, the address counter, word counter, and location counter ripple.
	Read Sel/Write Sel	This switch determines whether a read select or write select will be issued when the start button is depressed.
	Entry Switches	 These 36 switches are used to: Load data into the drum register. Load a drum address. Load an address into the location counter.
	Single Sector/Single Dru Loop Sector/Loop Drum	on/ This rotary selector designates the type of operation desired during CE Panel operations.

Area/Location System Development/Poughkeepsie		Date January 30, 1964		
Project	7289 Drum Channel		Project No.	
File Section	Functional Specifications		Section No.	
Systems Plannin or Area Manag	ger J. A. Giroux	Planning Rep. or Project Manager	H. J. Kozuch	

. 3.9.1 Switches

(Continued)

Single Sector/Single Drum/ Loop Sector/Loop Drum

- a. Single Sector. Off Line:
 Reading or writing begins at the
 beginning of the sector and continues
 to the end of the sector. On Line:
 Reading or writing begins at the starting
 drum address and continues to the end
 of the sector or word count zero.
- b. Single Drum:
 Same as single track except the end of a logical drum is used instead of the end of sector.
- c. Loop Sector:
 Same as single sector, except the operation is repeated continuously.
- d. Loop Drum:
 Same as single drum, except the operation is repeated continuously, returning to the beginning of the logical drum after each disconnect.

When a disconnect occurs while looping sector or drum on-line, the entry keys are examined for the location of the next command.

3.9.2 Pushbuttons

Reset:

This button resets all conditions in channel to the power on reset condition.

Load Drum Registers: The contents of the 36 entry keys are placed in the drum register.

- 1 Po	nubkeepsie Date January 30, 1964
/Location System Development/Po	Project No.
ect 7289 Drum Channel	Section No.
Section Functional Specifications ems Planning Area Manager J. A. Giroux	Planning Rep. or H. S. Kozuch Project Manager H. S. Kozuch
	ontinued)
Load Drum Address:	The contents of the 56 entry keys are placed in the drum address register and drum select register, and the proper drum and heads are set.
Load Location Counte	Tocation comme
Step Drum Address:	DAR 1-4 are stepped once for each depression and the new heads are set.
Write Format:	When this button is depressed, the format is automatically written on the selected drum if its format key is in the write position.
Start:	This button starts a read or write operation.
3.9.3 CE Sectors	leated by a five position rotary switch.
Four CE Sectors ar	e selected by a five position rotary switch. Off/1/2/3/4

3.9.4 Indicators

Check Stop

Indicates that the channel has stopped due to a check condition. See Section 3.9.1, Stop On Check and Data Compare switches.

3.10 Programming Considerations

RDS or WRS will turn on the prepare to read and prepare to write triggers respectively. These triggers will be turned off by a new RDS or WRS or by a RCHB instruction. If they are turned off by a RCHB, the read or write indicator will be turned on as the prepare to read or write trigger is turned off.

Area/Location_	System Development/Pol	ighkeopsie	Dote January 30, 1964	
Project 7289	Drum Channel	record restrictions and the second representative from the second restriction of the second rest	Project No.	
File Section	Functional Specifications		Section No.	
Systems Planning or Area Manage	J. A. Caroux	Planning Rep. or Project Manager	H. J. Kozuch	
3.10	Programming Consider	ations (Continued	i)	
	To assure proper opera conditions one of the fol			

Read Write

RDBB WRDB

RCHB A RCHB D
TCOB * TCOB *
TEFB B TEFB E
TRCB C IOT

IOT .

Channel In Use

The channel will be in operation from the time a RCHB is executed until a disconnect is issued.


End of File

End of file indicates an attempt to read or write past the boundaries of a logical drum.

Area/Loca	tion System Development/Pough	keepsie Date January 30, 1964
Project	7289 Drum Channel	Project No.
	on Functional Specifications	Section No.
Systems Pl	onning J. a. History Manager J. A. Chroux	Planning Rep. or H. J. Kozuch Project Manager H. J. Kozuch
4 PHYS	SICAL CHARACTERISTICS	
4.1	Size and Weight -	
	The 7289 Drum Channel consists dimensions and weight of this un	of one rack and panel unit. The it are as follows:
•	Weight Dimensions (inches) (lbs.) Front Side Height	Company of the Compan
	750 38 32 70	42 36 30 30
4.2	Power - 208/230 volts, 60 cycle The power connector is a Russe receptacle is a Russel & Stoll F shall vary a maximum of + 10%	o, 1 phase, 3 wire, 15 amps. 1 & Stoll FS 3750 plug. The mating S 3933. The input voltage regulation
4.3	Heat Dissipation -	
	The 7289 will dissipate 3970 BT	U/hour.
4.4	Temperature and Humidity - Temperat Operating (Power On) 50°-90° Non-operating 50°-110 (Power Off)	F 8%-80% 78°F
4.5	Cabling -	
	The total maximum cable length	between the 7289 Drum Channel and the

/1	tion System Development/Poughk	teepsie Date January 30, 1764
	• •	Project No.
roject	7289 Drum Channel	Section No.
ile Section	on Functional Specifications	and the same of th
ivstems Pl	Annage J. A. Ciroux	Planning Rep. or & J. Kozuch Project Manager H. W. Kozuch
Of Mica		
•	Data Characteristics	
	Revolution time	17.5 ms.
	Words per revolution (maximum)	2048
	Capacity per drum	6-32K memories
•	Instantaneous word rate	7.2 usec.
	Average word rate	8.4 usec.
	Instantaneous character rate	833 KC
	Revolutions to load 32K memory	16
	Time to load 32K memory	0.27 secs.
	Average access time	8.6 ms.

TABLE 1



PURPOSE:

TO INSTALL A TRAP FEATURE ON THE 7289 PARALLEL DRUM CHANNEL.

DESCRIPTION:

THE 7289 TRAP WILL FUNCTION AS FOLLOWS:

- THE TRAP IS ENABLED WITH THE SAME BIT AS USED TO ENABLE CW/EOF TRAPS ON THE 7607 DATA CHANNEL.
- THE TRAP IS RESTORED THE SAME AS THE 7607 DATA CHANNEL.
- TRAP ADDRESSES AND DATA STORED AT THESE ADDRESSES ARE THE SAME AS THE 7607 DATA CHANNEL.
- 4. THE THREE TRAP FLAGS ARE AS FOLLOWS:
- A. BIT 15 END OF FILE CONDITION
- B. BIT 16 REDUNDANCY CHECK
- C. BIT 17 OPERATION CONCLUDED.

INTERNATIONAL BUSINESS MACHINES CORPORATION

ENGINEERING INSTRUCTIONS

heet	ection	2
2	3 -	572
्र ९ ।	0	572526

DESCRIPTION (CONT'D)

- OPERATION CONCLUDED IS DEFINED TO INDICATE THAT A DISCONNECT CONTROL WORD (IOCD) IS BEING EXECUTED AND THE WORD COUNT HAS OF FILE, OR REDUNDANCY BEEN DECREMENTED TO EQUAL ZERO AND NEITHER AN I/O CHECK, END TRAP DEMAND CHECK HAS OCCURRED PRIOR TO ISSUING A
- .WITH TRAP INSTALLED, THE END OF FILE AND REDUNDANCY CHECK CHECK INDICATOR AND PREVENT TRAPS DUE TO THAT CONDITION. WILL RESET THE END OF FILE INDICATOR AND PREVENT TRAPS DUE TO INDICATORS ARE RESET WHEN A TRAP OCCURS. A TEF INSTRUCTION THAT CONDITION. A TRC INSTRUCTION WILL RESET THE REDUNDANCY
- IF THE CHANNEL IS NOT ENABLED PRIOR TO A NEW WRITE SELECT OR SELECT WILL BE RESET. READ SELECT BEING ISSUED THE TRAP CONDITION FOR THE PREVIOUS