

# GE-600 Mnemonics and Operation Codes



COMPUTER DEPARTMENT

	000	001	002	003	004	005	006	007	010	011	012	013	014	015	016	017
000																
020	ADLX0	MME	DRL	ADLX2	ADLX3	ADLX4	ADLX5	ADLX6	ADLX7			ADL		ADLA	ADLQ	ADLAQ
040	ASX0	ASX1	ASX2	ASX3	ASX4	ASX5	ASX6	ASX7					AØS	ASA	ASQ	
060	ADX0	ADX1	ADX2	ADX3	ADX4	ADX5	ADX6	ADX7			AWCA	AWCQ	LREG	ADA	ADQ	ADAQ
100	CMPX0	CMPX1	CMPX2	CMPX3	CMPX4	CMPX5	CMPX6	CMPX7		CWL				CMPA	CMPQ	CMPAQ
120	SBLX0	SBLX1	SBLX2	SBLX3	SBLX4	SBLX5	SBLX6	SBLX7						SBLA	SBLQ	SBLAQ
140	SSX0	SSX1	SSX2	SSX3	SSX4	SSX5	SSX6	SSX7						SSA	SSQ	
160	SBX0	SBX1	SBX2	SBX3	SBX4	SBX5	SBX6	SBX7		SWCA	SWCQ			SBA	SBQ	SBAQ
200	CNAX0	CNAX1	CNAX2	CNAX3	CNAX4	CNAX5	CNAX6	CNAX7		CMK				CNAA	CNAQ	CNAAQ
220	LDX0	LDX1	LDX2	LDX3	LDX4	LDX5	LDX6	LDX7	LBAR			RMCM	SZN	LDA	LQ	LDAQ
240	ØRSX0	ØRSX1	ØRSX2	ØRSX3	ØRSX4	ØRSX5	ØRSX6	ØRSX7						ØRSA	ØRSQ	
260	ØRX0	ØRX1	ØRX2	ØRX3	ØRX4	ØRX5	ØRX6	ØRX7						ØRA	ØRQ	ØRAQ
300	CANX0	CANX1	CANX2	CANX3	CANX4	CANX5	CANX6	CANX7						CANA	CANQ	CANAQ
320	LCX0	LCX1	LCX2	LCX3	LCX4	LCX5	LCX6	LCX7						LCA	LCQ	LCAQ
340	ANSX0	ANSX1	ANSX2	ANSX3	ANSX4	ANSX5	ANSX6	ANSX7						ANSA	ANSQ	
360	ANX0	ANX1	ANX2	ANX3	ANX4	ANX5	ANX6	ANX7						ANA	ANQ	ANAAQ
400	MPF	MPY				CMG				LDE				ADE		
420	UFM			DUFM		FCMG		DFCMG	FSZN	FLD		DFLD		UFA		DUFA
440									STZ	SMIC		SMFP		FST	STE	DFST
460	FMP			DFMP										FAD		DFAD
500	RPL					BCD	DIV	DVF		NEG		FNEG		FCMP		DFCMP
520	RPT			FDI		FDI		DFDI		STBA	STBQ	NEGL		UFS		DUFS
540						FDV		DFDV	SBAR			SMCM	STC1	FSB		DFSB
560	RPD											FNØ				
600	TZE	TNZ	TNC	TRC	TMI	TPL		TTF					TEØ	TEU	DIS	TØV
620	EAX0	EAX1	EAX2	EAX3	EAX4	EAX5	EAX6	EAX7	RET			RMFP	LDI	EAA	EAQ	LDT
640	ERSX0	ERSX1	ERSX2	ERSX3	ERSX4	ERSX5	ERSX6	ERSX7						ERSA	ERSQ	
660	ERX0	ERX1	ERX2	ERX3	ERX4	ERX5	ERX6	ERX7						ERA	ERQ	ERAQ
700	TSX0	TSX1	TSX2	TSX3	TSX4	TSX5	TSX6	TSX7	TRA					TSS	XEC	XED
720										ARS	QRS	LRS		ALS	QLS	LLS
740	STX0	STX1	STX2	STX3	STX4	STX5	STX6	STX7	STC2	STCA	STCQ	SREG	STI	STA	STQ	STAQ
760										ARL	QRL	LRL	GTB	ALR	QLR	LLR
000																