Contents

About This Manual vii
Customer Support ix

Part I The CM-5 I/O System

Chapter 1 Introduction to CM-5 I/O 3

1.1 I/O Components of the CM-5 System 3

1.2 CM I/O 7

1.2.1 Parallel I/O and Serial I/O 7

1.2.2 The Client-Server Model 8

1.3 CM-5 Data Format 9

1.4 The Connection Machine File Systems 9

1.4.1 Which File System Do You Want? 11

`CMFS_PATHTYPE` Syntax 12

Chapter 2 CM-5 File System Interfaces 15

2.1 CMFS Software vs. UNIX Software: What's the Difference? 16

2.2 Accessing the File Systems from C-Based Languages 17

2.2.1 Accessing the File Systems from C 17

2.2.2 Accessing the File Systems from C* 18

2.3 Accessing the File Systems from Fortran-Based Languages 18

2.3.1 Accessing the File Systems from FORTRAN 77 19

2.3.2 Accessing the File Systems from CM Fortran 19

Chapter 3 CM-5 I/O Performance Issues 21

3.1 Definition of Terms 21

3.2 Overview: Reading to and Writing from the CM-5 23

3.3 Obtaining Optimal File System Performance 24

3.3.1 Parallel I/O Performance 24

Copyright © 1994 Thinking Machines Corporation

3.3.2 Serial I/O Performance 25
3.3.3 Specific Performance Hints for C* I/O 25
3.3.4 Specific Performance Hints for CM Fortran I/O 26
3.4 Performing Small Transfers 26
3.5 Timing I/O Operations 26

Part II The CMFS Library and CMOST I/O

Chapter 4 Overview: CMOST I/O Commands and CMFS Library Routines . 31
4.1 The CMOST I/O Commands 31
4.1.1 The CMFS Library Routines 33

Chapter 5 Compiling, Running, and Debugging Programs That Contain CMFS Code 39
5.1 Preparing to Run Your Program 42
5.1.1 Our Sample Environment 42
5.1.2 Using the SDA 42
5.1.3 Using the DataVault 43
5.2 Compiling CMFS Code 43
5.3 Debugging CMFS Code 45
5.3.1 Automatic CMFS Debugging Messages 45
The `CMFS_DEBUG` Environment Variable 45
The `CMFS_set_debug_mode` Routine 46

Chapter 6 File Operations 47
6.1 Creating and Opening Files 47
6.1.1 `CMFS_open` 48
6.1.2 `CMFS_creat` 49
6.2 Changing a File's Permissions 51
6.3 Changing a File's Owner or Group 52
6.4 Moving a File Pointer 53
6.4.1 `CMFS_serial_lseek`, `CMFS_serial_dlseek`, `CMFS_serial_llseek` 54
6.4.2 `CMFS_physical_lseek` 55

Copyright © 199 Thinking Machines Corporation

6.5 Changing a File's Size 56
6.5.1 **CMFS_serial_[f]truncate_file**, **CMFS_serial_lftruncate_file**, and **CMS_serial_dftruncate_file** 57
6.5.2 **CMFS_physical_ftruncate** 58
6.6 Closing Files 58
6.7 Copying Files 59
6.7.1 General CMOST I/O Copy Commands 60
The **cmcp** Command 61
The **copytodv** and **copyfromdv** Commands 61
6.7.2 High-Performance Copy Commands: **dvcp** and **pcp** 62

Chapter 7 Reading and Writing 63

7.1 The Process 63
7.2 File Padding 64
7.3 CM I/O 64
7.3.1 CMFS Synchronous I/O Routines 64
7.3.2 CMFS Physical I/O Routines 66
7.3.3 CMOST I/O System Calls 67
7.4 Serial I/O 69
7.4.1 **CMFS_serial_read_file** on a VMEIO Host Computer 70

Chapter 8 Tape I/O 73

8.1 Using Tapes: An Overview 74
8.2 Creating and Restoring Tape Archives: The **cmdump** and **cmrestore** Commands 75
8.3 Storing and Retrieving Raw Data: The **cmdd** Command 84
8.4 Handling IBM Data Sets and Tape Labels: The **ibmtape** Command . . . 86
8.4.1 About IBM-Format Tapes 86
8.4.2 **ibmtape** Syntax 88
8.4.3 Reading Multiple Data Sets from a Single Tape 92
8.4.4 **ibmtape** Performance Issues 93
8.5 Tape Transfers Using Serial I/O 94
8.5.1 Sample Programs 97
Sample Program: **createFile** 97
Sample Program: **stageCopy** 99

Copyright © 1994 Thinking Machines Corporation

Part III Manual Pages

Chapter 9 CM-5 Environment Variables: Manual Pages **111**

Chapter 10 CM-5 CMFS Library Routines: Manual Pages **119**

Chapter 11 CMOST I/O System Calls: Manual Pages **237**

Chapter 12 CMOST I/O Commands: Manual Pages **245**

Appendixes

Appendix A The CMFS File System **311**

A.1 The CMFS File System 311

A.2 CMFS Files 314

A.2.1 Attribute Files 315

A.2.2 Sharing a CMFS File between a CM-5 and a CM-2 or CM-200 315

Data Format Conversion 316

Appendix B NMO Buffer Layout **317**

B.1 SDA Files Are in Canonical (Serial) Order 318

B.2 Buffer Layout 319

B.2.1 A `CM_read()` System Call 319

B.2.2 A `CM_write()` System Call 325

B.3 NMO on Vector Unit NMO Buffers 326

Index **329**

Copyright © 199 Thinking Machines Corporation