Chapter 9

CM-5 Environment Variables: Manual Pages

This chapter contains manual pages for the following CM-5 environment variables:

```
CMFS_DEBUG
CMFS_PATHTYPE
CM_ACCOUNT_ID
CM_NO_PN_CORE
DVHOSTNAME
DVWD
```


Copyright © 1994 Thinking Machines Corporation