Chapter 12

CMOST I/O Commands: Manual Pages

This chapter contains manual pages for the following CMOST I/O commands:

```
cmchgrp
cmchmod
cmchown
cmcmp
cmcp
cmdd
cmdf
cmdu
cmdump
cmfind
cmftp
cmglob
cmld
cmln
cmls
cmmkdir
cmmknod
cmmv
cmptruncate
cmrestore
cmrm
cmrmdir
cmstat
cmtar
cmtruncate
copyfromdv
copytodv
dvcp
ibmtape
pcp
```


Copyright © 1994 Thinking Machines Corporation