Contents

About This Manual . . . . . **v**
Customer Support . . . . . **vii**

Chapter 1 Introduction **1**

Chapter 2 Using the Integrated Tape System **5**

2.1 The **itsibmtape** Command 6
if=*inputfile*, **of=***outputfile* 6
[**-tosda** | **-fromsda**] 7
label={ **isl** | **ial** | **osl** | **oal** |
osl, **wsl** | **oal**, **wal** } 7
2.1.1 **vsn=***list_of_vol_serial_nos* 7
dsn=*data setname* 7
bs=*buffersize* 8
rformat=*fmt:blen:rlen* 8
[**stackers=***n*] 8
[**-leds**] 9
[**-compress**] 9
[**-a**] 9
2.2 The **itsdd** Command 10
ifbs=*n*, **ofbs=***n* 10
-tosda, **-fromsda** 10
2.3 The **itstar** Command 11
2.4 The **itsdump** and **itsrestore** Commands 12

Chapter 3 ITS Programming Examples **13**

3.1 Using **itsibmtape** 13
3.1.1 SDA to Tape Transfers 13
3.1.2 Tape to SDA Transfers 16
3.2 Using **itstar** 18
3.2.1 SDA to Tape Transfers 18
3.2.2 Tape to SDA Transfers 19

Copyright © 1994 Thinking Machines Corporation

3.3 Using **itsdd** 19

Appendix A IBM File and Tape Formats **21**

A.1 Data Set/File Formats 21

A.2 Tape Formats 23

A.2.1 Tape Labels 23

label=isl 25

label=osl 25

label=osl,**wsl** 26

A.2.2 Tape Files 26

Appendix B Performance Notes for itsibmtape **29**

Appendix C Manual Pages **31**

itsdd 32

itsdump 36

itsibmtape 41

itsrestore 50

itstar 54

Version 7.3, April 1994
Copyright © 1994 Thinking Machines Corporation