Index

A

accounting information, providing, 17
as, 7
assembly languages, 7, 74
at command, 18

B

batch command, 18
batch mode, executing in, 18

C

C shell, 84
C*, 83
  documentation for, 61
  overview of, 60
  porting program from CM-2/200 to CM-5, 78
  programming models for, 61
checkpointing, 79
CM Fortran, 83
  development and monitoring facilities, 59
  documentation for, 59
  intrinsic functions in, 59
  overview of, 57
  porting program from CM-2/200 to CM-5, 77
  programming models for, 58
  utility library, 59
CM-2/200, 9
CM-5
  distributed graphics strategy for, 65
  gaining access to, 15
  hardware of, 4
  networks in, 6
  operating system of, 8
  parallel programming on, 1
  software for, 6
  user's view of, 14
CM-HIPPI, 9
CM-IOPG, 10
CM/AVS, 65, 83
CM_ACCOUNT_ID, 17
CM_NO_PN_CORE, 21
CM5-HIPPI, 9
CMAX, 4, 8, 72, 83
  and Prism, 51
CMFS, 10, 83
CMIO bus, 10, 83
cmld, 17
CMMD, 3, 68, 84
  Active Message facility, 70
  block data transfers in, 70
  cooperative and asynchronous processing, 69
  documentation for, 71
  programming models for, 69
  supporting utilities, 71
  using Prism with, 51
CMOST, 8, 21, 84
cmpartition, 24
-cmprofile compiler option, 33, 45
cmps, 25
CMSSL, 84
  communication functions, 64
  FFTs, 63
  linear algebra, 62
  linear programming, 63
  ordinary differential equations, 63
  overview of, 61
  statistical analysis, 64
CMTSD_core_pn file, 21
CMTSD_dp.pn file, 21

Copyright © 1993–1994 Thinking Machines Corporation

CMTSD_errors file, 21
CMTSD_heap.pn file, 21
CMTSD_stack.pn file, 21
CMview, 11, 29, 49
CMX11, 66, 84
compiling, 16
Control Network, 6, 84
control processor, 5, 84
core files, 20
.cshrc, 84

D

Data Network, 6, 10, 84
data parallel programming, 2
data parallel software, 7
DataVault, 10, 84
debugging, 20
  within Prism, 38
Diagnostics Network, 6
directory, 85
DISPLAY environment variable, 34
DJM, 18
  status information for, 27
documentation, obtaining on-line, 29
dpas, 7
DPEAC, 7, 74

E

environment variables, 85
errors file, 20
event list, 40
executing, 17
  from within Prism, 36

F

file systems, 10

G

-g compiler option, 33

H

hostname, 85

I

I/O, 9
integrated environment, 65

J

jrun, 18
jstat, 27
jsub, 18

L

linking, 17
*Lisp, 7
  porting program from CM-2/200 to CM-5, 80

M

make utility, 85
man command, 31
man pages, 11, 31
message passing, 3, 7, 68
  See also CMMD

N

Node Prism, 51
nodes, 4, 85
NQS, 19
  status information for, 28

P

partition, 5, 85
partition manager, 5, 14, 85
  logging in to, 15
  logging out of, 16
pathname, 86

Copyright © 1993–1994 Thinking Machines Corporation

performance data, 45
PNs. *See* nodes
PostScript files for CM-5 manuals, 11, 32
Prism, 9, 20, 86
  and CMAX, 51
  and CMMD programs, 51
  commands-only mode, 50
  customizing, 50
  debugging in, 38
  debugging message-passing programs in, 51
  executing in, 36
  getting help in, 49
  leaving, 50
  obtaining performance data in, 45
  starting up, 34
  tour of, 34
  visualizing data in, 41
prism command, 34
  -C option, 50
process, 86
programs, sample, 13

Q

qstat, 28
qsub, 19

R

rlogin, 15, 86
rsh, 16, 86

S

sample programs, 13, 81
Scalable Computing, 4
Scalable Disk Array. *See* SDA
SDA, 9, 87
SFS, 10, 87
SPARC assembly language, 7
SPMD programming model, 2
symbolic link, 88
system status, finding out about, 25

T

timing utility, 22
tracebacks, 22

U

/usr/examples, 13

V

vector units, 5, 14, 21, 88
vector-unit memory, errors files for, 21
vector-unit registers, errors file for, 21
visualization programming, 65
visualizing data, 41

W

WorldView, 49

X

xcmps, 26

Copyright © 1993–1994 Thinking Machines Corporation